SECTION J

HORIZONTAL MORTISER


+

DOWELER

J1 J1

HORIZONTAL MORTISER + DOWELER

Horizontal Mortisers present a special challenge. Many of the tables are independent of the cutter head. They are separate tables that can move vertically, horizontally and back and forth. [X, Y and Z]. As such it becomes difficult to align the table to the mortise cutter. With the *MasterGage/Professional* it is easy and very fast to align the mortise table in X, Y and Z axis to the mortise cutter.




Square the Mortise table to the cutter head using the knife edge of the *MasterGage/Professional*

HINT: Use the ½ inch x 4 inch Precision Rod for alignment. Its smooth, super straight surface is far more accurate than using a cutter.

HORIZONTAL MORTISER + DOWELER

Horizontal Mortisers present a special challenge. Many of the tables are independent of the cutter head. They are separate tables that can move vertically, horizontally and back and forth. [X, Y and Z]. As such it becomes difficult to align the table to the mortise cutter. With the

MasterGage/Professional it is easy and very fast to align the mortise table in X, Y and Z axis to the mortise cutter




Setting the cutter height

HINT: When using the Precision Rod, simply subtract ¼ inch to find the center of the mortise required.

HORIZONTAL MORTISER + DOWELER

Horizontal Mortisers present a special challenge. Many of the tables are independent of the cutter head. They are separate tables that can move vertically, horizontally and back and forth. [X, Y and Z]. As such it becomes difficult to align the table to the mortise cutter. With the

MasterGage/*Professional* it is easy and very fast to align the mortise table in X, Y and Z axis to the mortise cutter




Set the cutter depth required and lock table stops.

HINT: Use the actual mortise cutter bit for this set up. Set the Mortise/Doweler table travel for the depth cut.

HORIZONTAL MORTISER + DOWELER

J4

Horizontal Mortisers present a particular challenge since many of the tables are independent of the cutter head. Usually on separate tables that can move vertically, horizontally and back and forth. [X, Y and Z]. As such it becomes difficult to align the table to the cutter head and mortise cutter for a correct mortise cut on the wooden part. The *MasterGage/Professional* handles this problem easily.



Set the distance required for the mortise length and lock table stops.

HINT: Use the actual mortise cutter bit for this set up. Set the Mortise/Doweler table travel for the mortised slot width.